



INSTALLATION & MAINTENANCE MANUAL

**SKR2 / SKR9**

## GENERAL INSTRUCTIONS

**These instructions should be read carefully and retained after installation by the end user for future reference and maintenance.**


**These instructions should be used to aid installation of the following product:  
SKR2 / SKR9**

## SAFETY

- This product must be installed in accordance with the latest edition of the IEE Wiring Regulations (BS7671) and current Building Regulations. If in any doubt, consult a qualified electrician
- Please isolate mains prior to installation or maintenance
- Check the total load on the circuit (including when this product is fitted) does not exceed the rating of the circuit cable, fuse or circuit breaker
- Please note the IP (Ingress Protection) rating of this product when deciding the location for installation
- Do not overload this accessory or subject it to conditions outside its rating
- This product is Class I and must be earthed
- This product is for indoor use only
- This product is IP20 rated


## INSTALLATION

- Provide power to the required point of installation (refer to BS7671 for correct cabling methods)
- Locate a suitable place to mount the product
- Remove the screws on the front cover using a slotted screwdriver (see Fig. 1)
- Mark the location of the fixing holes and drill the holes ensuring not to infringe with any gas/water pipes or electrical cables (see Fig. 1)



**Fig. 1**

- Feed the mains cable into the unit and secure the base to the surface
- Connect to the mains supply ensuring the correct polarity is observed (see Fig. 2) L – Live (brown), E – Earth (green/yellow) and N – Neutral (blue)




**Fig. 2**

- An earth connection must be made and maintained. Use green/yellow sleeving on earth conductors that are not insulated
- Check all electrical connections are secure with all exposed copper within the terminal and no loose strands of cable
- Attach the front cover screws
- Screw in both front cover screws
- Fit screws covers over screws
- Switch on and check for correct operation

## WARNING

This product must be disconnected from the circuit if subjected to any high voltage or insulation resistance testing. Irreparable damage will occur if this instruction is not followed.



USB or Bluetooth products, dimmers, shaver sockets and products with LED or neon indicators must be disconnected from the circuit if subjected to any high voltage or insulation resistance testing. Irreparable damage will occur if this instruction is not followed. Please note this kind of damage will void the warranty. Please note that we do not recommend our 13A sockets be used for Electric Vehicle (EV) charging for prolonged periods.

## GENERAL

This product should be recycled in the correct manner when it reaches the end of its life.

Check local authorities for where facilities exist.

Clean with a soft dry cloth only, do not use aggressive cleaning products or solvents which may damage the product and invalidate the warranty

## WARRANTY

This product has a warranty of 2 years\* from date of purchase. Failure to install this product in accordance with the current edition of the IEE Wiring Regulations (BS7671), improper use, or removal of the batch code will invalidate the warranty. If this product should fail within its warranty period, it should be returned to the place of purchase for a free of charge replacement. ML Accessories does not accept responsibility for any installation costs associated with the replacement product. Your statutory rights are not affected. ML Accessories reserve the right to alter product specification without prior notice.

\* 2 years for products with electronic components such as dimmers, USB chargers etc. Knightsbridge Wiring Accessories have a warranty of 25 years\* for mechanical operation from date of purchase with the exception of products containing electronic components such as dimmers, USB chargers, and speaker products], which have a 2-year warranty. Failure to install this product in accordance with the current edition of the IEE Wiring Regulations (BS7671), improper use, or removal of the batch code will invalidate the warranty. If this product should fail within its warranty period, it should be returned to the place of purchase for a free of charge replacement. ML Accessories does not accept responsibility for any installation costs associated with the replacement product. Your statutory rights are not affected. ML Accessories reserve the right to alter product specification without prior notice.

**SUPPLIED BY:**

**(UK) MANUFACTURER**

**ML ACCESSORIES LTD**, UNIT E CHILTERN PARK,  
BOSCOMBE ROAD, DUNSTABLE LU5 4LT,  
WWW.MLACCESSORIES.CO.UK

**(EU) AUTHORISED REPRESENTATIVE**

**SLV LIGHTING GROUP**,  
DAIMLERSTRASSE 21-23,  
52531 ÜBACH-PALENBERG, GERMANY  
**EMAIL: EPREL@GROUP.SLV.COM**

MADE IN CHINA



**ML**  
ACCESSORIES LTD

